

PORATAMATICULAS ADAPTABLE HONDA CBR600RR 07'-12' LICENSE SUPPORT ADAPTABLE TO HONDA CBR600RR 07'-12'

REF:4453N



INSTRUCCIONES DE MONTAJE

- 1- Desmontar el portamatriculas original (Para facilitar la operación es aconsejable desmontar en primer lugar la base sillín trasera y la delantera. A continuación sacar el colín) .
- 2- Previo al montaje de los laterales(8) pasar las bridas de plástico para fijar la instalación eléctrica por los agujeros(6).
- 3- Montar los soportes laterales usando los tornillos allen M6x10 en la posición 4 y M6X20 en la posición 3. Los intermitentes deben montarse en la posición 5.
- 4- Montar a continuación el soporte central(9) usando los tornillos M6x10 (2) y las tuercas M6(1). Ajustar los laterales mediante la regulación que ofrece el conjunto y apretar.
- 5- Finalmente montar el piloto trasero(7) y fijar los cables con las bridas de plástico.

INSTRUCTIONS TO ASSEMBLE

- 1- Dismount the original license support (in order to make easy the assembling process we recommend to dismount the front and rear seat base. Next, take off the back cowl).
- 2- Before mounting the side parts of the license bracket (8) place the bristles to tight, afterwards, the electrical installation through the holes (6).
- 3- Mount the side parts of the license bracket using the allen fasteners M6x10 (2) on position 4 and M6x20 on position 3. The turn signals must be mounted on position 5.
- 4- Afterwards, tighten the central support (9) using the M6x10 (2) and the M6 nuts (1). Adjusts these side parts through the regulation that the set offers and tighten it.
- 5- Finally, mount the back light (7) and tight the cables with the plastic bristles.

Material sumistrado para el montaje en la motocicleta:

Material supplied to assemble the license support:

POSICIÓN	DENOMINACIÓN	CANTIDAD
1	Tuercas M6 DIN6923 c/blanco	2
2-4	Tornillos M6X10 DIN1001 c/blanco	4
3	Tornillos M6X20 DIN1001 c/blanco	2
6	Bridas de plástico	5
7	Piloto trasero	1
8-9	Soportes portamatriculas	3

