

Sissybar

HONDA CTX 700 / N / DCT

Artikel-Nummer:
611984 00 01 mit Gepäckbrücke

Artikel-Nummer:
600984 00 01 ohne Gepäckbrücke



Montage

Der Bausatz umfaßt die folgenden Teile:

Stück	Bestellnr.	Bezeichnung
-------	------------	-------------

Sissybar mit Gepäckbrücke

1	700008555	Sissybar
1	700008528	Gepäckbrücke
1	700008561	Halteadapter links
1	700008562	Halteadapter rechts
1	700008526	Brückenadapter links
1	700008527	Brückenadapter rechts

ODER

Sissybar ohne Gepäckbrücke

1	700008555	Sissybar
1	700008561	Halteadapter links
1	700008562	Halteadapter rechts
1	700008526	Brückenadapter links
1	700008527	Brückenadapter rechts

Schraubensatz 700008556

12	Linsenkopfschraube M8 x 20mm
12	U-Scheiben Ø8,4

Sissybar mit Gepäckbrücke



Sissybar ohne Gepäckbrücke



Anzugsmomente des Motorradherstellers beachten!
Nach der Montage alle Verschraubungen auf festen Sitz kontrollieren!
Bitte beachten Sie unsere beigefügten Serviceinformationen.

Als weiteres Zubehör lieferbar:

Kofferträger Lock it (abnehmbar)	Art.-Nr.: 650.984 00 01
Motorschutzbügel	Art.-Nr.: 501.984 00 01
C-Bow Halter für Softtaschen	Art.-Nr.: 630.984 00 01



Hepco & Becker GmbH
An der Steinmauer 6
D-66955 Pirmasens

Tel.: 06331 - 1453 - 100
Fax: 06331 - 1453 - 120
eMail: vertrieb@hepco-becker.de
www.hepco-becker.de

Sissybar

HONDA CTX 700 / N / DCT

Artikel-Nummer:
611984 00 01 mit Gepäckbrücke

Artikel-Nummer:
600984 00 01 ohne Gepäckbrücke



Montage


1

Vorbereitung:
Sitzbank abnehmen, Seitenverkleidung demontieren. Aus den Seitenverkleidungen die Blenden demontieren.

Montage der Halteadapter links + rechts:
diese werden an den freien Gewinden am oberen Rohrrahmen unter der Verkleidung (ehemals Blenden) mit den Linsenkopfschrauben M8x20 sowie U-Scheiben Ø8,4 verschraubt.
Seitenverkleidung wieder montieren.




4x 4x




2

Befestigung der Brückenadapter links und rechts:
mit den Linsenkopfschrauben M8x20 sowie U-Scheiben Ø8,4 an den Halteadaptern.

Schrauben noch nicht festziehen.



4x 4x



Sissybar

HONDA CTX 700 / N

Item-no.:

611984 00 01 with rear rack

Item-no.:

600984 00 01 without rear rack



Assembling instructions

The kit includes the following parts:

Quant	item no.	description
-------	----------	-------------

Sissybar with rear rack

1	700008555	Sissybar
1	700008528	Rear rack
1	700008561	adapter left
1	700008562	adapter right
1	700008526	rack adapter left
1	700008527	rack adapter right

OR

Sissybar without rear rack

1	700008555	Sissybar
1	700008561	adapter left
1	700008562	adapter right
1	700008526	rack adapter left
1	700008527	rack adapter right

Screw kit 700008556

12	Filister head screw M8 x 20mm
12	Washer Ø8,4

Sissybar with rear rack



Sissybar without rear rack



Control all screw connections after the assembling for tightness!

Please notice our enclosed service information.

Also available:

Side carrier (Lock it, can be removed)

Engine guard

C-Bow Holder for softbags

Item-No. 650.984 01 01

Item-No. 501.984 00 01

Item-No. 630.984 00 01



Hepco & Becker GmbH
An der Steinmauer 6
D-66955 Pirmasens
Germany

Tel.: +49 6331 - 1453 - 100

Fax: +49 6331 - 1453 - 120

eMail: vertrieb@hepco-becker.de

www.hepco-becker.de

Sissybar

HONDA CTX 700 / N

Item-no.:
611984 00 01 with rear rack

Item-no.:
600984 00 01 without rear rack



Assembling instructions

Preparing:


Remove the seat and remove side panels.
Dismantle the little covers in the side panels.

Fastening of the adapters left + right:
at the free threads on top of the frame tubes with filister head screws M8x20 and washers Ø8,4.

Mount side panels again.




1




Fastening of the rack adapters left + right:
with filister head screws M8x20 and washers Ø8,4 at the adapters, mounted in step 1.

Do not screw on yet.



2



Sissybar


HONDA CTX 700 / N

Item-no.:
611984 00 01 with rear rack

Item-no.:
600984 00 01 without rear rack




Assembling instructions





3

Fastening Sissybar without rear rack: _____
between the adapters.
Use filister head screws M8 x 20 mm with washers $\varnothing 8,4$.




4x

4x



4

Fastening Sissybar with rear rack: _____
between the adapters. Rear rack position is between adapter and
Sissybar.
Use filister head screws M8 x 20 mm with washers $\varnothing 8,4$.



4x

4x

